



Automatic Sustainable Controller, ASC



DEIF A/S · Frisenborgvej 33 · DK-7800 Skive Tel.: +45 9614 9614 · Fax: +45 9614 9615 info@deif.com · www.deif.com

Document no.: 4189341077B SW version: 4.55.x or later

1. General information	5
Warnings, legal information and safety	5
Warnings and notes	5
Warnings	5
Notes	5
Legal information and disclaimer	5
Disclaimer	5
Safety issues	5
Electrostatic discharge awareness	5
Factory settings	5
About the commissioning guide	6
General purpose	6
Intended users	6
Contents and overall structure	6
2. Introduction	7
3. Commissioning overview	8
4. IP and ID plan	9
5. Power source data	10
6. Configuration of digital power meter	11
7. Single line diagram	12
Application configuration, stand-alone	12
Example	13
Application configuration, power management	14
Power management CAN bus	15
8. Wiring overview	16
9. AC configuration	17
Scaling	17
10. Power supply alarms	18
Power supply	18
11. Breaker connections	19
PV Breaker is present	19
Mains Breaker is present	21
Genset breaker feedback inputs	22
12. Generator configuration	23
Generator parameter settings	23
Nominal power	23

ASC commissioning guide 4189341077 UK

Power inputs	24
Active power inputs	24
Reactive power inputs	25
13. Mains configuration	26
Mains parameter settings	26
14. PV configuration	27
Scaling	27
PV nominal values	27
Nominal power	
Nominal ratings	
Nominal current	29
Nominal voltage	
Nominal frequency	31
15. Communication setup	
Modbus master, Serial 2	
Type selection	
Breaker feedback on DPM	
16. PV Communication setup	35
Modbus master, serial 1	35
Modbus protocol and write type	
Verification of the communication	
Alarms for unicast communication	
Alarms for broadcast communication	
ADFweb setup	
17. E-stop	40
Emergency stop	40
18. Operating modes	41
Stand alone system.	41
Set points off-grid	41
Set points grid-tied	41
Power management system.	42
Set points	42
19. Spinning reserve	43
Spinning reserve alarms	43
Dynamic spinning reserve	43
Origin of spinning reserve	44
20. Auto start/stop	45
21. Transducer setup	46

Ν	/ulti-input setup	.46
Т	ransducer signals	.46
	4-20 mA values	.47
	Testing procedure of the transducer signals	47
21.	Appendix, modified parameter list	.53

1. General information

Warnings, legal information and safety

Warnings and notes

Throughout this document, a number of warnings and notes with helpful user information will be presented. To ensure that these are noticed, they will be highlighted as follows in order to separate them from the general text.

Warnings



Warnings indicate a potentially dangerous situation, which could result in death, personal injury or damaged equipment, if certain guidelines are not followed.

Notes



Notes provide general information, which will be helpful for the reader to bear in mind.

Legal information and disclaimer

DEIF takes no responsibility for installation or operation of the generator set. If there is any doubt about how to install or operate the engine/generator controlled by the Multi-line 2 unit, the company responsible for the installation or the operation of the set must be contacted.



Disclaimer

DEIF A/S reserves the right to change any of the contents of this document without prior notice.

The English version of this document always contains the most recent and up-to-date information about the product. DEIF does not take responsibility for the accuracy of translations, and translations might not be updated at the same time as the English document. If there is any discrepancy, the English version prevails.

Safety issues

Installing and operating the Multi-line 2 unit may imply work with dangerous currents and voltages. Therefore, the installation should only be carried out by authorised personnel who understand the risks involved in working with live electrical equipment.



Be aware of the hazardous live currents and voltages. Do not touch any AC measurement inputs as this could lead to injury or death.

Electrostatic discharge awareness

Sufficient care must be taken to protect the terminal against static discharges during the installation. Once the unit is installed and connected, these precautions are no longer necessary.

Factory settings

The Multi-line 2 unit is delivered from factory with certain factory settings. These are based on average values and are not necessarily the correct settings for matching the engine/generator set in question. Precautions must be taken to check the settings before running the engine/generator set.

About the commissioning guide

General purpose

This commissioning guide mainly includes general product and hardware information, mounting instructions, terminal strip descriptions, I/O lists and wiring descriptions.

The general purpose of this document is to give the user important information to be used in the installation of the unit.



Please make sure to read this document before starting to work with the Multi-line 2 unit and the inverter to be controlled. Failure to do this could result in human injury or damage to the equipment.

Intended users

This commissioning guide is mainly intended for the person responsible for the design and installation. In most cases, this would be a panel builder designer. Naturally, other users might also find useful information in the document.

Contents and overall structure

This document is divided into chapters, and in order to make the structure simple and easy to use, each chapter will begin from the top of a new page.

2. Introduction

The commissioning guide is for the PV controller in the ASC series.

There are a few steps to follow when the ASC is configured. During the planning of the commissioning job, it can be useful to check whether the ASC is installed in the DEIF cabinet or in a customer-designed cabinet.

This document can be used in both cases.

The document contains the AGC terminal numbers even if installed in a switchboard. Please refer to the switchboard diagrams to see the actual terminal block and terminal number. If in doubt, ask the switchboard designer.

3. Commissioning overview

Before the commissioning is started, preparing a work breakdown structure must be created. This will hold the necessary planning from start to end of the commissioning comprising things like mechanical works, electrical DC works, electrical AC works and so on.

This guide only focusses on the WBS concerning the ASC configuration.

	DEIF control system commissioning
4	Create IP list of all devices in the plant with IP addresses and adjust
	Create list of power meters and inverters connected to the ASC with their ID numbers and baud
	rate and adjust
5	Create a complete list of the power source data
6	Configure all DPM from front face with CT ratio, PT ratio and relevant others
7	Establish communication with the ASC with PC Utility SW
7	Configure the application configuration
8	Wiring overview and parameters associated with the terminals
9	Configure AC configuration and scaling of the ASC
10	Configure power supply alarms
11	Configure settings for the breaker control and feedbacks PV breaker
11	Configure settings for the breaker feedbacks mains breaker
11	Configure input settings for breaker feedbacks
21	Configure multi-inputs 102,105,108
12	Configure generator values (nominal, power readings (P/Q) from input and scaling)
13	Configure mains values (power input (P/Q) and scaling)
14	Configure nominal values [U,I,f,P,S,Q,CT ratio, PT ratio] of the PV
15	Configure DPM for mains incomer (number, ID and baud rate)
15	Configure DPM for generator (number, ID and baud rate
15	Configure DPM for PV (number, ID and baud rate)
15	Configure M-Logic with breaker feedbacks from MIC 4000 series
16	Configure inverter type, IDs and baud rate
17	Emergency stop
18	Configure plant modes and set points
18	Configure minimum DG load
19	Configure spinning reserve alarms
20	Configure M-Logic with AUTO start/stop
21	Transducer setup

4. IP and ID plan

It is necessary to know all IDs and IP addresses of the plant. Below is an example. Please create a suitable IP plan in Excel so this is ready before commissioning.

These parameters are needed for the commissioning

ASC test scheme, suggested communication data				
Device	IP Address	MODBUS ID, monitoring	MODBUS ID for control	BAUDRATE
ASC	-	10	-	19200
ADFWEB HD67510	172.170.10.2		0	19200
	-			
Inverter #1	172.170.10.10	10	126	
Inverter #2	172.170.10.11	11	126	
Inverter #3	172.170.10.12	12	126	
Inverter #4	172.170.10.13	13	126	
Inverter #5	172.170.10.14	14	126	
Inverter #6	172.170.10.15	15	126	
Inverter #7	172.170.10.16	16	126	
Inverter #8	172.170.10.17	17	126	
Inverter #9	172.170.10.18	18	126	
DPM - MIC 4002 (mains)	-	1		19200
DPM - MIC 4002 (generator#1)	-	2		19200
DPM - MIC 4002 (generator#2)	-	3		19200
DPM - MIC 4002 (generator#3)	-	4		19200

Example only above.

Plug	Function	Associated menus
RJ-45	ASC device IP number	9000
		(9002=IP/GW)(9003=SM)

5. Power source data

Similar to getting an overview of the IDs and IPs, the power source data must be found and be ready before the commissioning.

power source data									
	H7	v	Amn	n	PF	Р	CT ratio	PT ratio	number
nonorotor 1	50	400		5	0.0	500	1000/5	4.4	01
generator	50	400		623	0,8	500	1000/5	1.1	
generator 2	50	400		625	0,8	500	1000/5	1:1	
generator 3	50	400		480	0,8	384	1000/5	1:1	
mains	50	400		600		480	1000/5	1:1	
solar panel						265 W			2100
						557			
solar park						kW			
inverter size				60					9
inverter total	50	400	779	540			1000/5	1:1	

The above shows an example with one mains incomer and 3 generators. There are nine 60 kW inverters in the plant.

6. Configuration of digital power meter

With the collected information, it is possible to configure the digital power meters. If transducers are used instead of digital power meters, they must be configured instead.

Depending on the type of power meter, the configuration menu is accessed from the front, and configuration is done from the front. The programming of transducers and power meters are not done from the DEIF PC Utility SW.

On DEIF power meters, for instance MIB 7000C, the configuration menu is typically accessed by pressing "H"+ "VA" simultaneously.

Please refer to the programming manual of your specific meter.

7. Single line diagram

The DEIF controller contains the single line diagram. In DEIF terms, this is represented with the "Application configuration". There are two possibilities; the stand alone application or an integrated power management application.

The name "stand alone" means there is only one DEIF ASC in the system. Hence the term standalone.

Application configuration, stand-alone

The application can be adjusted by using the PC utility SW. In the tab on the left hand side, the "application configuration" can be selected. Then the configuration is done by selecting the plant specifics.



This example shows the plant with one ASC in a configuration with grid. The number of generators in the application cannot be configured on this screen unless it is a power management application.

The generators are configured in the "Input settings" or in "M-Logic".

However, they will not be seen in the picture of the application configuration! A maximum of sixteen (16) generators can be configured.

Example:

This is a typical stand-alone application. The application configuration is shown below:



As mentioned, the generators are not visible in the "application configuration". However, they are present in the plant. There are two generators in this example.

For configuration of the generators, please see separate complete section in this document.

See the configuration of the PV breakers in the separate chapter about the PV Breaker wiring (control and feedback).

Application configuration, power management

The power management provides a lot of combinations. The below screenshot shows only an example.

Special for the power management application is that there is one controller per power source. In the example below, there are five DEIF Multi-line 2 controllers (AGCs and ASCs).

۲	DEIF utility software - 3.40.0; Connected to "ASC PM Solar" (version 5.04.0 rev. 25075) – 🗖 🗙
File Connection	
DEIF	Area control Plant totals
	< Area 3 of 5 > Application 2: PV APPLICATION DK Area configuration _ Top
AHE	Source Mains
Device	D 31
Device	
	MB Pulse V
Application supervision	TB Pulse V
	Normally closed V
Alarms	D 0 (*) TB31
	Normally open V
Trending	Vdc breaker V BTB34 BTB35
æ,	
	Bottom GB1 GB2
Parameters	Source None
Inputs/Outputs	
	<add add="" delete=""></add>
<u> </u>	
Options	
Logs	
⁹ é	
Translations	
~~~~~	
-FR. AND OR NOT	
M-Logic	
Application	
configuration	
	interstamp Active Ackistatus Ackiaction
	<no data="" display="" to=""></no>
Communication	nactive Connected to *ASC PM Solar* (version 5.04.0 rev. 25075) IP 192.168.100.2 (ID 3)

In the designer's reference handbook of the AGC, the power management configuration is described. Please refer to www.deif.com/products/AGC-4 for additional details about the application configuration.

See the configuration of the PV breakers in the separate section about the PV Breaker wiring (control and feedback).

#### Power management CAN bus

These menus are used if the ASC is part of an integrated system (power management system). The menus are not used if the ASC is the only controller in a stand-alone system.

Terminal	Function		Associated menus
A1	Power management communication	CAN H	7841, CANport select 7870, actions at CAN failure
A3	Power management communication	CAN L	

Notice that the CAN bus line has to be terminated in each end with a 120 Ohm resistor. The recommended CAN bus cable is Belden 3105A or Lapp CAN bus cable.

# 8. Wiring overview

Some basic wiring is needed before engaging the ASC in the system. These terminals must be wired in most cases.

This terminal overview of the ASC is used in the case:



This terminal overview of the ASC contains the hardware options M12-E2-H2-M14.6-M15.8. Other combinations of the option configuration will of course have different terminal overviews. In the installation manual, the precise I/O list of the separate options is shown.

# 9. AC configuration

#### Scaling

Select the scaling to the proper setting. There are four to choose between but only two will normally be used.

Note that you must do this before the rest of the nominal values are set up in order to have the easiest setup sequence.

If this selection is made from the display unit, you must press the key JUMP (keyJUMP, then keyUP or keyDOWN until you reach menu 9030). The master password is still needed.

Menu	Function	Comment
9030	10-2500 V AC	The master password must be used Typical choice
	100-25000 V AC	Typical choice

The difference between 10-2500 V AC and 100-25000 V AC is the way the power is presented. For instance 6 kW is presented as 6.0 in the lower scale (10-2500 V AC) and 6 kW in the second level scale (100-25000 V AC). So for low power installations, it is recommended to use 10 -2500 V AC.

🧭 DEIF utility soft	tware - 3.42.0.1164, PDB 5199 [DEBUG VERSIO	N]; Connected to "ASC-4 Sol	ar" (version 4.04.0 rev. 28769)	- 0	×
File Connection	n Parameters Help				
•• - 🔅 <b>&amp; &amp;</b>	🖉 • 🔓 🖬 🗊 🖏 • 📸 🤮 🔍 🖢	🖏 🕫 🕫 🖉 🕹	😽 🎘 🔎 🗵 💷 🎝 - 🔲 🗊 🕼 🥸 🍼 🚯 🎯 👘 🌧 希		
DEIF	View mode:	◯ List			
	> · PV dynamics		AC Configuration		
	<ul> <li>Weather data</li> <li>AC Configuration and alarms</li> </ul>	AC config.			
L _M	- AC power origin	Description:	Menu is used to choose between the different AC measurement systems.		
Application	- AC Configuration			🏷	' 🚖
supervision	> Current	Setpoint:	3 phase L1L2L3 V		
×	> · Voltage				
	> Breakers	Scaling			
Alarms	> Busbar	Description:	Select the voltage range of operation	💌 🏹	
	> Inputs	Setpoint:	100V-25000V ~		
i i i i i i i i i i i i i i i i i i i	> Outputs				
Trending	> · Communication				
	Horn				
	Display M-Logic alarms				
Parameters	Battery/AUX supply				
+++	Pulse counters     Command timers				
° Louis	Passwords				
Inputs/Outputs	> · Application				
<u>e</u> _h					
8					
Ontions					
opuona					
Logs					
^o é					
<u>i</u>					
Translations					
0R NOT					

# 10. Power supply alarms

# Power supply

These alarms will alarm if the power supply fails. The menus 4980/4990 are only present if the option G5/M4 is installed.

Terminal	Function	Associated menus
1	24 V DC power supply	4960 aux supply low voltage 4970 aux supply high voltage
2	Negative for terminal 1	
98	24 V DC power supply	4980 aux supply low voltage 4990 aux supply high voltage
99	Negative for terminal 98	

# 11. Breaker connections

#### **PV Breaker is present**

If the application configuration includes a PV breaker, the following terminals must be wired:

Terminal	Function		Comments
14	Open PV Breaker	NO	Open relay is used depending on breaker type: pulse
15	Common for 14/16	Comm	
16		NC	
17	Close PV Breaker	NO	Closed relay is used depending on breaker type: pulse and continuous (contactor)
18	Common for 17/19	Comm	
19		NC	

It is noted that the breaker configuration is set up in the "Application configuration". There are no parameter menus for this. Compact breaker (MCCB) is not supported by the ASC.

These menus and inputs associate with each other.

Terminal	Function	Associated menus
26	Feedback for the PVB open position	2160 PVB open failure 2180 PVB pos failure
27	Feedback for the PVB closed position	2170 PVB close failure 2180 PVB pos failure
28	Common for 26 and 27	

Breaker feedback can be checked in the utility software on the inputs/outputs page. Note that the input terminal numbers are mentioned on the right hand side of the terminal description.

🧭 DEIF utility soft	🤗 DEIF utility software - 3.42.0; Connected to "ASC-4 Solar" (version 9.91.0 rev. 0) - 🗆 🗙					<			
File Connection	Parameters Hel	p							
] •• • 🔅 🎗 🎗	🖉 • 📔 🖬	🔁 🖷 🎽 🕰	🔟 🔘 🕏	Þ	🖻 🔅 📕 😽 🏂	🔬 🖸 🛄 🗶	🔳 👖 👹	🖲 🕑 🕲	)
		Input status				Output status			
DEIF	PVB pos. feedb.	OFF	26	^	Relay 57		57-58	~	
	O PVB pos. feedb.	ON	27		Relay 59		59-60		
+++ 📥	Emergency stop		118		Relay 61		61-62		
* <del></del>	Oigital input 117		117		Relay 63		63-64		
111	Digital input 116		116		Relay 5		5-6-7		
Inputs/Outputs	Oigital input 115		115		Relay 8		8-9-10		
<mark>։ ի</mark>	Oigital input 114		114		Relay 11		11-12-13		
<u>8</u> -	Digital input 113		113		Relay 14		14-15-16	_	
	Digital input 112		112		PVB ON relay		17-18-19		
Options				~	Delay 20		20.22	~	
	Legend :	State undetermined	State	low	State high	Ref	fresh VO texts	;	
Logs	Text		Timestamp		• • • • • • • • • • • • • • • • • • •	Active	Ack status	Ack action	
^Ø é <b>▼</b> ▪	<no data="" display="" to=""></no>								
Communication	active Connected to "ASC-4 Solar" (version 9.91.0 rev. 0) IP 192.168.11.184 (ID 3)								

When there is a PV Breaker in the application and the ASC controls it, the application always contains one:



#### Mains breaker is present

No control of the mains breaker is present. But it is necessary to wire in position feedbacks so that the ASC knows the status of the mains breaker. This is the case for non-power management systems (ASC is the only DEIF controller in the system).

Terminal	Function	Associated menus
24	Feedback for the MB open position	2210 MB pos failure
25	Feedback for the MB closed position	2210 MB pos failure
28	Common for 24 and 25	

The check of the input functionality is done in the inputs/outputs page similar to the PVB. The application will contain a breaker which is not controlled by the ASC



#### Genset breaker feedback inputs

The mentioned parameters, wiring and settings must be configured when it is not a power management system. Notice that the DPM DEIF MIC 4000 series also gives the possibility to configure this in the "M-Logic" programming tool.

Note the available number of inputs is option-dependent. The below shown 43-48 (56:common) belong to option M12.

Terminal	Function		Associated menus
43	Genset #1 breaker is closed		7481 DG1 nominal power
44	Genset #2 breaker is closed		7482 DG2 nominal power
45	Genset #3 breaker is closed		7483 DG3 nominal power
46	Genset #4 breaker is closed		7484 DG4 nominal power
47	Genset #5 breaker is closed		7485 DG5 nominal power
48	Genset #6 breaker is closed		7486 DG6 nominal power
			Maximum 16 gensets can be configured
56	Common for 43-55	Com.	

0	I/O settings	×	
Inputs Outputs			
GB 1 on busbar		^	
I/O number / function	Dig. input 43, Term 43 🗸 🗸		
GB 2 on busbar			
I/O number / function	Dig. input 44, Term 44 🗸 🗸		
GB 3 on busbar			
I/O number / function	Dig. input 45, Term 45 🗸 🗸		
GB 4 on busbar			
I/O number / function	Dig. input 46, Term 46 🗸 🗸		
GB 5 on busbar			
I/O number / function	Dig. input 47, Term 47 🗸 🗸		
GB 6 on busbar			
I/O number / function	Dig. input 48, Term 48 🗸	~	
		Close	2
		0.000	

Select the desired inputs in the I/O settings, which are accessed from the horizontal toolbar.

# 12. Generator configuration

#### Generator parameter settings

Before starting on this setup, please adjust the multi-inputs 102, 105, 108 to the needed input type, for instance 4-20 mA inputs. This applies only for units with option G5/M4 and if the transducer inputs are being used.

The chapter describes the configuration and setup of the generator and mains values. It is easily done in the utility software.

You need to go through these steps when the system is a stand-alone system. If the system is an integrated power management system, the ASC retrieves the data from the power management communication lines.

#### Nominal power

Note that the generator power is adjusted in kW rather than kVA. The kW value can be found by multiplying the kVA value of the generator with 0.8.



In this example, there is one generator, called DG1 and its size is 100 kW.

#### **Power inputs**

The "power inputs" define where the ASC receives the data from for the generator power.



Above, it is indicated that the ASC uses the multi-input 105 for the input that represents the active power of the generator.

#### **Reactive power inputs**



Above, it is indicated that the ASC uses the multi-input 108 for the input that represents the reactive power of the generator.

# 13. Mains configuration

#### Mains parameter settings

The mains configuration is used in stand-alone applications which contain a mains feeder.

Ø DEIF utility sof	tware - 3.42.0; Connected to "ASC-4 Solar" (v	ersion 9.91.0	rev. 0)					_		Х
File Connection	n Parameters Help									
- š & &	8 🖉 • 📂 🗔 💭 • 🕋 🖂 🔖	🖏 🕹 🕻	* 🖻 🔅 🔳	褐 鷞 🥖 Σ 🛄 🕈	5- 🗉 🗊 🧐	ତ 🛛 🐨 🗍	🧊 🛸 😒 🚖	\$		
DEIF	View mode:    Tree	OList								
	> PV dynamics	^		N	1ains power	r inputs				
	<ul> <li>vveatner data</li> <li>AC Configuration and alarms</li> </ul>	Main	s P input							
<u>البلسية:</u>	> Breakers		Description:	Input selection for main	is power					_
Trending	<ul> <li>✓ Plant</li> </ul>		Setpoint:	Analogue input 91	~			€		<b>*</b>
<u></u>	···· Genset/plant mode									
	···· Minimum DG load	Main	s Q input							
Parameters	Stand-alone PV     Power set points		Description:	Input selection for main	is reactive power					
***	Mains power export and Peak	sl	Setpoint:	Analogue input 93	~			*		*
+++	···· Pixed power ···· Optimum dispatch									
Inputs/Outputs	··· Q reference grid-tied									
8	··· P/Q limitation									
-	DG nominals     DG power inputs									
Options	DG reactive power inputs									
•	External control HMVSCADA									
	Alarms									
Logs	> · Outputs									
^ø é]∕	> Communication									
Translation	Horn									
ransiauons	Display M-Logic alarms									
	Battery/AUX supply									
(Nor)	<ul> <li>Pulse counters</li> <li>Command timers</li> </ul>									
-Logic	C Decemente	> `								
	Text		Timestamo	····· ¥		Active	Ack statue	Acker	tion	
Application			rinestamp			HOUNG	AUX SIGUS	AUX di	Judii	
configuration				<no data="" display="" to=""></no>						
Communication	n active Connected to "ASC-4	Solar" (versio	n 9.91.0 rev. 0)		IP 192.168.11.184 (II	D 3)				

The above shows that the active power of the mains import/export is measured on the analogue input 91 and the reactive power on analogue input 93 (in this example!).

It is voluntary to use the "Mains Q input" if the ASC is only doing kW control of the inverters or are running the inverters at a fixed PF.

# 14. PV configuration

#### Scaling

Select the scaling to the proper setting. There are four to choose between but only two will normally be used.

Note that you must do this before the rest of the nominal values are set up in order to have the easiest setup sequence.

If this selection is made from the display unit, you must press the key JUMP (keyJUMP, then keyUP or keyDOWN until you reach menu 9030). The master password is still needed.

Menu	Function	Comment
9030	10-2500 V AC	The master password must be used Typical choice
	100-25000 V AC	Typical choice

The difference between 10-2500 V AC and 100-25000 V AC is the way the power is presented. For instance 6 kW is presented as 6.0 in the lower scale (10-2500 V AC) and 6 kW in the second level scale (100-25000 V AC). So for low power installations, it is recommended to use 10-2500 V AC.

#### **PV** nominal values

In the section "Power source data", all AC values were collected. Now they can be entered into the ASC.

#### Nominal power



#### **Nominal ratings**

Menu	Function	Comments
6002	Adjust the rating of the installed PV panels.	For example 200 250 Wp modules are installed. Adjust in this menu 200*250*10^- 3=50 kW.
6005	Adjust the Q rating of the inverter	If given. Otherwise, adjust to the same value as 6006.
6006	Adjust the S rating of the inverters.	For example three 20 kVA inverters are installed. Adjust this menu to 3*20=60 kVA.

#### **Nominal current**

The voltage and current measurements need to be connected and set up in the menus.

Terminal	Function		Associated menus
73	PV IL1	S1	6003, I nominal 6043, CT primary 6044, CT, secondary
74	PV IL1	S2	
75	PV IL2	S1	
76	PV IL2	S2	
77	PV IL3	S1	
78	PV IL3	S2	



Also adjust the CT settings of the CTs connected to the CT input terminals of the ASC.

#### Nominal voltage

Terminal	Function		Associated menus
79	UL1	PV	6004, U nominal PV 6041, U PT primary 6042, U PT secondary
80			
81	UL2	PV	
82			
83	UL3	PV	
84	Ν	PV	

If no PT is installed and the voltage is wired directly into the ASC, the ratio is set to 1:1. For example 415:415 on a 415 volt system.

Terminal	Function		Associated menus
85	UL1	BUS	6053, U nominal PV BUS 6051, U PT primary 6052, U PT secondary
86			
87	UL2	BUS	
88	Ν	BUS	
89	UL3	BUS	

Notice that the terminal for the neutral is placed between L2 and L3.

Ø DEIF utility soft	tware - 3.42.0; Connected to "ASC-4 Solar" (versio	n 9.91.0 rev. 0)				– 🗆 ×	
File Connection	n Parameters Help						
🗠 - 🐳 🕄 🎗	- ※ ※ ※ ※ 😰 🖕 🔛 🔛 👘 🥶 🗘 🔟 🗘 💆 🗘 🦈 р 🦚 🏣 🤯 🦧 🔟 🏗 🦛 🕼 🖉 🖉 👘						
DEIF	View mode:	Clist					
	> PV dynamics		Nomir	nal Settings			
	> · \vestmer data	Nom. U 1 Description: Setpoint:	Nominal PV voltage set point 1	400 × V (1	100 25000)	۱	
Parameters	Nominal Settings     Overvoitage Protection     Undervoitage Protection     Trip Selection     Trip Selection     Frequency	Nom. U 2 Description: Setpoint:	Nominal PV voltage set point 2	400 × V (1	100 25000)	چ 🖉	
Options	> Burbar > Burbar ✓ Plant — Genset/plant mode — Spinning reserve — Minimum DG load	Nom. U 3 Description: Setpoint:	Nominal PV voltage set point 3	400 🔦 V (1	100 25000)	🔊 🖉	
Logs	Stand-alone rv     Stand-alone rv     Sover set points     Mains power export and Peak si     Fixed power     Optimum dispatch     Q reference grid-lied     Q reference off-grid	Nom. U 4 Description: Setpoint:	Nominal PV voltage set point 4	400 × (1	100 25000)	۱	
Translations	PIQ limitation     DG nominals     DG nominals     DG reactive power inputs     Mains power inputs     External control HM/SCADA     Aturne						
	Text	Timestamo	······ •	Active	Ack status	Ack action	
Application configuration		. mosturiy	<no data="" display="" to=""></no>	, teare	, ten otuno	r con accent	
Communication	n active Connected to "ASC-4 Solar	(version 9.91.0 rev. 0)	IP 192.16	8.11.184 (ID 3)			

Also adjust the PT ratio if PTs are used. They must always be checked if the scaling has been configured to 10-2500 V AC.

#### **Nominal frequency**



# **15. Communication setup**

#### Modbus master, Serial 2

The ASC can read the power (active and reactive) from various digital power meters or Modbus devices. The Modbus serial communication connections are located in slot #8 in the ASC as shown:

Terminal	Function		Associated menus
131	Modbus communication	В	<ul> <li>7720, DPM protocol type (for example DEIF MIB 7000C) and number of nodes</li> <li>7730-7750, action at DPM Communication error (Modbus master)</li> <li>7700 Comm ID and baud rate</li> <li>7710, action at communication error</li> </ul>
100	Madhua communication	٨	
133	Moubus communication	А	

Note that the meters have their own Modbus parameters (ID and baud rate). Adjust these on the meters directly, typically on the front display of the DPM.

Note that when using the Modbus master, serial 2 for measuring the mains, generator and/or PV power, it is not necessary to use the transducers for measuring the power sources.

#### Type selection

It is noted that the types of power meters can be mixed. However, on the same type of source, the same type of instruments must be installed.

Source	Power meter selection	Comment for the example
Gen 1	MIC 4002	Must be equal to gen2 and 3
Gen 2	MIC 4002	Must be equal to gen1 and 3
Gen 3	MIC 4002	Must be equal to gen1 and 2
Mains	MIB 7000C	

#### Breaker feedback on DPM

MIC 4002 and MIC 4224 include inputs that can be used as various breaker feedbacks. This is practical if the DPM is installed near the generator so additional feedback wiring over a large distance is avoided.

In DEIF M-Logic, the feedbacks are configured. This example includes 3 generators and 1 mains incomer.

#### ASC commissioning guide 4189341077 UK

•	Logic 1			Item o	description (optional and saved in	project file	e only)	
			Event A		Operator	-		Event B
•		NOT 🗌	DG Power meter1 input1: DG power meter inputs	$\sim$	OR	$\sim$	NOT	Not used
•			-					
•			Enable this rule 🗹 🔔			Output	GB1 closed feedba	ck: GB feedbacks 🗸
					lease in the continued and a read in	and a station		
	Logic 2			Item o	rescription (optional and saved in	project nie	e only)	
•			EventA		Operator			Event B
•			DG Power meter2 input1: DG power meter inputs	~	OR	$\sim$		Not used
•			_ I					
•			Enable this rule			Output	GB2 closed feedba	ck: GB feedbacks
	Logic 3			Item o	description (optional and saved in	project file	e only)	
			EventA		Operator			Event B
•		NOT 🗌	DG Power meter3 input1: DG power meter inputs	$\sim$	OR	$\sim$	NOT 🗌	Not used
•								
•			Enable this rule 🔽 🥁			Output	GB3 closed feedba	ck: GB feedbacks 🗸
•	Logic 4			Item o	description (optional and saved in	project file	e only)	
			EventA		Operator			Event B
•		NOT 🗌	Mains Power meter1 input1: Mains power meter inputs	~	OR	$\sim$	NOT 🗌	Not used
•								
			Enable this rule 🗹 🔔			Output	MB closed feedbac	k: MB feedbacks 🗸 🗸
	Logic 5			Item o	description (optional and saved in	project file	e only)	
▲		_	EventA		Operator	_	_	Event B
•		NOT	Mains Power meter1 input2: Mains power meter inputs	$\sim$	OR	$\sim$	NOT	Not used
•								1
•			Enable this rule 🗹 🥁			Output	MB open feedback:	MB feedbacks ~

Notice that in the M-Logic, the power meter number should be read as "the first", "the second", "the third" and so on.

Example:

Device	Modbus ID, monitoring	Logic line (in example)	Associated DPM
DPM - MIC 4002 (mains)	1	4/5	Mains power meter 1
DPM - MIC 4002 (generator#1)	2	1	DG power meter 1
DPM - MIC 4002 (generator#2)	3	2	DG power meter 2
DPM - MIC 4002 (generator#3)	4	3	DG power meter 3

Note that the Modbus ID must strictly be configured as different. And its assignment can be given depending on where it is connected, for instance gen breaker closed feedback.

#### Example:

Common point of	Power source	Modbus DPM	Modbus ID
connection or building			(M-Logic order)
Building 1	PV#1	MIC 4002	1
Building 2	PV#2	MIC 4002	2
Building 3	PV#3	MIC 4002	3
Building 4	PV#4	MIC 4002	4
Building 5	PV#5	MIC 4002	5
Building 6	PV#6	MIC 4002	6
Building 7	PV#7	MIC 4002	7
Building 8	PV#8	MIC 4002	8
Building 9	PV#9	MIC 4002	9
Building 10	PV#10	MIC 4002	10
Basement MSB	DG1	MIC 4002	11 (first)
Basement MSB	DG2	MIC 4002	12 (second)
Basement MSB	DG3	MIC 4002	13 (third)
Mains Tx	Transformer #1	MIC-2	14
Mains Tx	Transformer #2	MIC-2	15

M-Logic orders are used when configuring the breaker feedbacks on the MICs.



# 16. PV Communication setup

#### Modbus master, serial 1

Using the communication interface requires the use of Modbus master for the Sunspec-supported inverters or inverters with proprietary protocols.

Terminal	Function		Associated menus
29	Modbus communication	A	<ul> <li>7561, PV Comm type (for example Sunspec)</li> <li>7570, action at PV Communication error (Modbus master)</li> <li>7510 Ext comm ID and Baud rate</li> <li>7520, action at communication error (Modbus slave)</li> </ul>
31	Modbus communication	В	

Note that the Modbus line should be properly terminated. Long lines typically with 120 Ohm in each. For short lines, it is often seen that the termination can be removed, but it also depends on the inverter type.

Note that the Modbus ID in the inverter can be set to the same as in the ASC. The baud rate has to be the same in the ASC and the inverter.

#### Modbus protocol and write type

The Modbus transmit specifics is set in menu 7560:

- 7561, select the inverter type.
- 7562, select broadcast or unicast
  - o Broadcast at multiple string inverters
  - o Unicast at single string inverters or central inverters
- 7563, transmit rate, set it to 1-2 seconds. Don't set it below 1 second unless advised to.

• 7564, transmit telegram, use 0x06h prior to 0x10h. Switch to 0x10h if 0x06h is not responding

Schneider, ABB uses 0x10h, Fronius, SMA uses 0x06h, inverters following Sunspec uses 0x06h.

#### Verification of the communication

Notice that it is often convenient to start with the communication adjusted to "UNICAST" even though broadcast is eventually going to be used.

Inverter number	Inverter Modbus ID	Baud rate selected	DEIF ASC comm. ID
1	10	19200	Menu 7511
2	11	19200	Menu 7511
3	12	19200	Menu 7511

Now switch to unicast and adjust the DEIF ASC to a proper ID:

Inverter number	Inverter Modbus ID	Baud rate selected	DEIF ASC comm. ID
1	10	19200	10
2	11	19200	-
3	12	19200	-

<b>A</b> A						
All groups		Prot Sync Reg Dig Ain	Out 🗌 Gen	Mains	Comm [	Pm
Channel	Δ	Text	Value	Unit	Timer	Enabled
	7501	Comm. bus control P	N/A		N/A	
	7502	Comm bus ctrl cosphi	N/A		N/A	
	7503	Comm. bus control Q	N/A		N/A	
₽	7511	Ext. comm. ID	<b></b> 10		N/A	
	7512	Ext. Comm.Speed	1		N/A	
	7513	Ext. Comm. Mode	0		N/A	
	7520	Ext comm. error	N/A		10	

This means that the inverter number 1 will be tested and should respond to the ASC set points. By switching the menu 7511 to ID11 and ID12 (in this example), the other two inverters can be tested.

This means that the communication can be verified and eventually switched to "broadcast" (where all three inverters will respond).

Not all inverters support this method of using unicast.

#### Alarms for unicast communication

Three alarms can be used when using the unicast approach (due to the continuous handshake with the inverter communications). In a communication topology where the broadcast method is used, the alarms can be switched off due to one-sided communication (ASC→inverter).

7	70 PV COMM error	N/A	3 🔽
7	80 PV Warning	N/A	3 🔽
7	90 PV Shutdown	N/A	0 🔽

- 7570, PV comm error
- 7580, PV warning
- 7590, PV shutdown

Enable the alarms and configure the appropriate actions.

#### Alarms for broadcast communication

When broadcast is used and the inverters receive set points using broadcast frames, the PV Monitoring alarm can be used. This is only the case if "PV monitoring" is switched on and receiving data back from the inverters.

If the broadcast frames are sent to a common inverter manager, for instance Fronius Data Manager Box 2.0, the ASC does not retrieve data from the inverters. Then the alarm "PV Monitoring error" cannot be used.

- 7570, PV comm error
- 7580, PV monitoring error

Enable the alarms and configure the appropriate actions.

#### **ADFweb setup**

In order to install the ADFweb HD67510 device in the application where it is required, for example using SMA STP25000 TL, follow these steps:

1. Install the PC utility from <u>www.adfweb.com</u> and find the utility on the free download page:

HD67510-A1	Modbus Slave / Modbus TCP Master - Converter	User manual	SW67510 (free download)	Ver. 2.201
11007510 02	(nousing oper real inter blocks connectors )	🚟 🕨 BS67510-A1 ENG	Configurator - Software	
		Box Sheet		
		BS67510-B2 ENG		
		Box Sheet		

2. Make a configuration with the relevant settings. This is the programme layout:

Web	ADFweb.com - Configurator SW67510 - Modbus SI	ave / Modbus TCP Master
	67510 Nave / Modbus TCP Master - Converter	
Begin	Opened Configuration of the Converter : DEIF_Allan	
Step 1	New Configuration	
Step 2	Set Communication	
Step 3	Translate Table	
Step 4	🔆 Update via UDP	www.ADFweb.com

- 3. When setting up the communication
  - a. use the routing table
  - b. set up the IP address you intend the HD67510 to have
  - c. set up the Modbus slave details (communication to DEIF ASC)
  - d. don't disconnect the socket
  - e. enable broadcast with ID 0

nmunication	- 🗆 ×
	¥
Modbus Sla	ve
Serial	RS485 v
Baudrate	9600 🗸
Parity	NONE 🗸
ID Device	1
✓ Enable E	Broadcast message with ID zero
	✓ ОК
	Modbus Sla Serial Baudrate Parity ID Device I Enable E

- 4. Set up the translate table
  - a. Set up slave ID 0 for broadcast using UDP Broadcast and route it to the IP of the inverter.

(Note that the desired slave ID address of the inverter has to be checked in the user manual of the inverter – 126 is for example for SMA STP25000 TL).

- b. Repeat steps for the number of IP addresses you have in your system (the example below shows a system with two (2) inverters).
- c. For remote monitoring (ASC reads from inverters), set up the translate table with your connected inverters, for example in this case, there are two inverters where the ASC reads from ID10 and ID11.
- d. All connected inverters must be included in the table for remote monitoring.

NDR WEb	Translate Table – 🗖 🗙						×		
Set	SW67510 Set Translate Table								
N°	Slave ID	IP Address TCP	Slave ID TCP	Reserved Sock	Errors Sock	UDP	Broadcast	Mnemonic	^
1	0	192.168.0.101	126				Image: A state of the state		
2	0	192.168.0.102	126				Image: A start of the start		
3	10	192.168.0.101	126						
4	11	192.168.0.102	126						
5									
6									
7									
8									
9									
10									~
	V OK Cancel Schere Row								

5. Update the settings to the ADFweb (check ADFweb manual for factory IP address).

Update Firmware from Etherner (UDP)	×			
SW67510 Update Firmware from Etherner (UDP)				
Insert the IP Address of HD67510				
Check the Connection the device				
Cancel Next				

Notice the dip switch position of the ADFweb. Both dip 1 and dip 2 have to be checked according to the manual from ADFweb. If one them is wrong, you cannot programme the device.

# 17. E-stop

# **Emergency stop**

The emergency stop will send a 0 kW reference to the PV plant and open the PV breaker if it is present.

The fail class can be selected to warning if the alarm input has to be used for other purpose.

Menu	Function		Comments
3490	Emergency stop details		Emergency stop alarm consists of sub menus.
3491	Timer		If used as e-stop then select 0 sec.
3492	Relay output for PLC	OA	
3493	Relay output for PLC	OB	
3494	Enable this alarms		
3495	Select fail class		If used as e-stop, then select S/D.

# 18. Operating modes

All modes are described in the designer's reference handbook of the ASC and the AGC in more details.

#### Stand-alone system.

In a stand-alone system, the requested mode is adjusted in the menu 6071.

Plant mode		
6070	Operating mode	Menu group
6071	Island mode	
	Fixed power	
	Mains power export	
	Power management	

#### Set points off-grid

In off-grid mode, the set point will be as high as possible but will be curtailing the PV in order to keep the genset minimum load. There are two different min. load settings in case you have different engine types.



#### Set points grid-tied

The set points during grid-tied operation are adjusted in the ASC. In the tree structure, the peak shaving, power export and fixed power values can be selected and adjusted.

🧭 DEIF utility soft	ware - 3.42.0.1164, PDB 5199 [DEBUG VERSION]; C	onnected to "ASC-4 Sol	ar" (version 4.04.0 rev. 28769)		- 0	×
File Connection	n Parameters Help					
🗠 - 🔅 🎗 🎗	- 🖉 • 📓 💭 🖏 • 🕋 🎒 🔽 🖉	) 🗢 🖻 🖻 🖏 📕	😽 🏂 🥖 Σ 🛄 🔩 🛛 🗊	🏽 🥸 💕 🚺 🍞 📑 💱	i 💱 🔂 🚖 🖈 🔏	
DEIF	View mode: <ul> <li>Tree</li> </ul>	) List				
	> · PV dynamics		Mains power expo	rt and Peak sh	aving	
	Weather data     AC Configuration and alarms     Desclored	Mains Power Exp				
	> · Busbar	Description:	Mains Power Export reference			<u> </u>
Application supervision	✓ · Plant Genset/plant mode	Setpoint:		1000 KW (-	20000 20000)	<b>_</b>
<u>*</u>	Spinning reserve Minimum DG load	Dook Showing				
	✓ · Stand-alone PV	Peak Silavilig	Dook Chaving reference			
Alarms	<ul> <li>Power set points</li> <li>Mains power export and Peak si</li> </ul>	Description.	Peak Shaving reference		S 🖉	
	Fixed power Optimum dispatch	Setpoint:		750 kW (-	.20000 20000)	
Trending	···· Q reference grid-tied	MPE/PS scale				
	- P/Q limitation	Description:	Scaling of the PS/MPE reference			
Parameters	DG power inputs DG reactive power inputs	Setpoint:	1kW:1kW 🗸			
+++	Mains power inputs					
	Alarms					
Inputs/Outputs	> · Outputs					
8	> · Communication Language Horn					
Options	Display					
	- M-Logic alarms - Battery/AUX supply					
	Pulse counters     Command timers					
Logs	< Decemente V					
°é }⊒	Text	Timestamp	······································	Active	Ack status Ack action	
Translation			<no data="" display="" to=""></no>			
t. Communication	active Connected to "ASC-4 Solar"	(version 4.04.0 rev. 287)	59) IP 192.168.11	1.184 (ID 3)		

# Power management system.

In an integrated system, the power management selection is needed. The actual mode is transmitted on the power management communication

Plant mode		
6070	Operating mode	Menu group
6071	Island mode	
	Fixed power	
	Mains power export	
	Power management	

#### Set points

The set points are communicated with the power management system. For the DG minimum load setting, refer to the same settings as mentioned in the stand-alone system above.

# 19. Spinning reserve

The ASC has two main functions with spinning reserve.

#### Spinning reserve alarms

Two alarms can be enabled. They can drive alarm relays and display alarms. These signals can be used as a driver to start additional generators or trip load groups. Since the DEIF controller only raises the alarm, the associated actions must be configured in the peripheral system (for instance third party genset controllers and load groups PLCs).



#### Dynamic spinning reserve

The DEIF ASC supports the feature "dynamic spinning reserve" in power management systems.

There are two settings, spinning reserve off-grid and grid-tied, and it depends on being grid-tied or not, which one is active.

> · PV dynamics	Spinning reserve				
> · Weather data					
> · AC Configuration and alarms	Spin. reserve		· · · · · · · · · · · · · · · · · · ·		
> · Breakers	Description:	Spinning reserve in mains parallel operation			
> · Busbar	Description.	opining reserve in many parallel operation			
✓ · Plant	Setnoint	<b>0</b> % (0, 100)			
···· Genset/plant mode	oupoint.				
Spinning reserve					
Minimum DG load	Spin, reserve				
✓ Stand-alone PV	opinitocorro				
✓ · Power set points	Description:	Spinning reserve in island operation			
Mains power export and Peak shave			- 🏂 🥖 🚖 🗌		
Fixed power	Setpoint:	10 🗘 % (0 100)			
···· Optimum dispatch					
···· Q reference grid-tied					
···· Q reference off-grid	Spin. reserve				
P/Q limitation	Description:	Origin of spinning reservation			
DG nominals			👟 🥖 🎍		
DG power inputs	Setpoint:	ASC settings ~			
DG reactive power inputs		-			
Mains nower inputs					

If adjusted to 10 %, the setting will reserve that on the generators. In this way, the generator plant can always instantly supply the set amount. The setting refers to the actual PV production, hence it is a dynamic spinning reserve because the pv production may vary.

#### Origin of spinning reserve

Note that the spinning reserve setting can be taken from the ASC, or a PLC can write the data into the ASC. This is adjusted in the last setting, and the default is "ASC settings".

# 20. Auto start/stop

In order to automatically start and stop the production from the inverters, it is recommended to configure a condition in M-Logic that ensures that the start signal is there while the controller is in full automatic:

If switches, operators, PLC, Scada or other methods are used, of course this setup is not needed or may vary depending on the requested.



# 21. Transducer setup

#### **Multi-input setup**

This applies only to units purchased with the option M4 or G5.

Multi-input 102, 105, 108 are configured to 4-20 mA signals in menus 10980/10990/11000 in the utility SW.

Notice that the 4-20 mA inputs of the option M4 are multi-inputs, and they must be configured correctly in the DEIF Utility SW.

Parameter "Multi inp. conf. 102" (Channel 10980)	Parameter "Multi inp. conf. 105" (Channel 10990)	Parameter "Multi inp. conf. 108" (Channel 11000)
Setpoint :	Setpoint :	Setpoint :
4-20mA V	4-20mA 🗸	4-20mA 🗸
Password level : customer V	Password level : v	Password level : customer v
Enable	Enable	Enable
High Alarm Inverse proportional	High Alarm	High Alarm
Auto acknowledge	Aito acknowledge	auto acknowledne
Inhibits	Inhibits	Inhibits V
Write OK Cancel	Write OK Cancel	Write OK Cancel

This has to be done as one of the first steps before configuring the transducer inputs. Normally, these are always kept as 4-20 mA signal inputs.

#### **Transducer signals**

Generator and mains power (active and/or reactive) can be read by the ASC using transducer signals or by using Modbus RS-485. In this chapter, using the transducer method is described.

Eleven transducer inputs may be available namely four inputs on each of M15:6 (91, 93, 95, 97) and M15:8 (127, 129, 131, 133) plus the three signals described below concerning to option M4/G5. (102, 105, 108).

Note that the three inputs should be set to 4-20 mA (assuming your transducers are 4-20 mA) before starting configuring this as described in the section Multi-input setup.

Terminal	Function		Associated menus
			example
103	4-20 mA input for mains power	+	4120, mains power 20 mA value 4120, mains power 4 mA value
104		-	
			example
106	4-20 mA input for genset summated power	+	4250, DG power 20 mA value 4250, DG power 4 mA value
107	•	-	
			example
109	4-20 mA input for genset summated reactive power	+	4380, DG reactive power 20 mA value 4380, DG reactive power 4 mA value
110		-	

#### 4-20 mA values

It is strictly necessary to adjust the 4-20 mA values of the connected transducer. This is done like the following example for a 4-20 mA mains transducer with the configuration of:

	Power [kW]	Current out [mA]
Power import from grid	700 kW	20 mA
Power export to grid	-700 kW	4 mA

Parameter "4-20mA 102.1" (Channel 4120)			
Setpoint : 4 mA value 700	0	20 mA value 700	
Timer : 0	120 sec	999	
Fail class :	Warning V	]	
Output A	Not used V	]	
Output B	Not used V		
Password level :	customer V		
	Commissio	ning	
Enable I High Alarm	Actual value : 274		
Inverse proportional	Time elapsed : 0 se	ec (0 %)	
Auto acknowledge	0 sec	120 sec	
	Write OK	Cancel	

Press the dotted line in front of the value to modify it.

#### Testing procedure of the transducer signals

It is essential to test the transducer signals into the DEIF controller. Please follow these steps to verify the good functionality. All 4-20 mA inputs may be used. In the example, the mains power transducer is used (multi-configurable input 102).

Terminal	Designation
102	Not used
103	+ (4-20)
104	0 (com)

#### Mains transducer

Open the MB (Mains Breaker). Now zero amps will flow to or from the mains.

	Power [kW]	Current out [mA]
MB open position	0 kW	12 mA

ASC commissioning guide 4189341077 UK

Display view, translated (suggestion)	Display view master language
PV380.0 380.0 380.0V Mains kW 0kW PROTECTION SETUP <u>PROT</u> CTRL I/O SYST	PV380.0 380.0 380.0V Analog 102 0mA PROTECTION SETUP <u>PROT</u> CTRL I/O SYST
	Parameter "4-20mA 102.1" (Channel 4120)   Setpoint: 20

Close the MB without any generation in the plant. Current will flow into the plant (depending on load demand):

	Power [kW]	Current out [mA]
MB closed position	352 kW	16 mA

Display view, translated (suggestion)	Display view master language	
PV380.0 380.0 380.0V Mains kW 352kW PROTECTION SETUP <u>PROT</u> CTRL I/O SYST	PV380.0 380.0 380.0V Analog 102 352mA PROTECTION SETUP <u>PROT</u> CTRL I/O SYST	
	Parameter "4-20mA 102.1" (Channel 4120)   Setpoint :   20	

Synchronise and close the MB when there is generation in the plant. Current will flow out of the plant (depending on load demand):

	Power [kW]	Current out [mA]
MB closed position	-349 kW	8 mA

Display view, translated (suggestion)	Display view master language	
PV380.0 380.0 380.0V Mains kW -349kW PROTECTION SETUP <u>PROT</u> CTRL I/O SYST	PV380.0 380.0 380.0V Analog 102 -349mA PROTECTION SETUP <u>PROT</u> CTRL I/OSYST	
	Parameter "4-20mA 102.1" (Channel 4120)   Setpoint :   20	

#### Translation

In the translations page, the multi-inputs can be translated:

Displayed translation:

(#### signifies the live value)

#### ASC commissioning guide 4189341077 UK

۲			DEIF utili	
File Connection	Para	meters Help		
] 🚥 + 🚎 🎗 🎗	2 -	💕 🖬 🐏 📸 🎒	🔟 🖸 🤣 🖻 🖍 🎲 🔳 😽 🎫 🗈 💷	
Ana 🏔 🛷 🛠				
(DEIF)	DEIF Master			
	Status	Master language 🛛 🛆	Language 1 (Your language)	
		After last ACK	After last ACK	
		Alarm ND	Alarm ND	
		Alarm NE	Alarm NE	
Device		Amb. temp. N.A	Amb. temp. N.A	
		Amb. temp. ###.# C	Amb. temp. ###.# C	
L/A		Analog 102	Analog 102	
Application supervision		Analog 102 #####mA	Mains kW #####kW	
		Analog 102 ###.#mA	Analog 102 ###.#mA	
		Analog 102 ##.##mA	Analog 102 ##.##mA	

Parameter list translation: (note #### signifies menu number).

3		DEIF utilit
File Connection	n Parameters Help	
🛛 🕶 - 🐳 🎗 🎗	। 🖉 • 📔 🗟 • 📸 🎒	🛕 🔟 🖉 🖻 🖻 🖓 🌆 😽 🔊 🕐
	Ana 🏦 🗸 🗙	
	Master	
	Status Master language	△
	#### 4-20mA 95.1	#### 4-20mA 95.1
	#### 4-20mA 95.2	#### 4-20mA 95.2
	#### 4-20mA 97.1	#### 4-20mA 97.1
Device	#### 4-20mA 97.2	#### 4-20mA 97.2
	#### 4-20mA 102.1	#### Mains power
L _A	#### 4-20mA 102.2	#### 4-20mA 102.2

#### Transducer testing tables

Fill in the readings of the display/utility SW as the example above shows. This will give a good indication whether the configuration is correct.

Display reading	Multi-conf. input 102	Multi-conf. input 105	Multi-conf. input 108
Signal mA	NVV	NVV	KVV
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			

# 21. Appendix, modified parameter list

An example of the modified parameter list for the ASC. The parameter list may seem overwhelming when opened but some main groups may be worked on.

As it may be noted, about ~35 parameters need to be changed in order to get a functioning system.

This list is an example of a stand-alone system comprising a specific inverter.

Drag a column header here to group by that column									
:	Channel 🛛 🛆	Text	Value	Unit	Timer	Enabled	Level	Mismatch	FailClass
₽	2611	P ramp up	5	%/s	N/A		customer		N/A
	2621	P ramp down	5	%/s	N/A		customer		N/A
	3490	Emergency STOP	N/A		0		customer		Shutdown
	4250	4-20mA 105.1	10		5		customer		Warning
	4380	4-20mA 108.1	10		120		customer		Warning
	6002	Nom. P 1	80	kW	N/A		customer		N/A
	6003	Nom. I 1	116	А	N/A		customer		N/A
	6004	Nom. U 1	400	v	N/A		customer		N/A
	6005	Nom. Q 1	80	kvar	N/A		customer		N/A
	6006	Nom. S 1	80	kVA	N/A		customer		N/A
	6041	BA primary U	400	v	N/A		customer		N/A
	6043	BA Primary I	150	А	N/A		customer		N/A
	6044	BA Secondary I	5	А	N/A		customer		N/A
	6051	BB primary U 1	400	v	N/A		customer		N/A
	6053	BB Nominal U 1	400	v	N/A		customer		N/A
	6061	BB primary U 2	400	v	N/A		customer		N/A
	6063	BB Nominal U 2	400	v	N/A		customer		N/A
	6071	Operation mode	0		N/A		customer		N/A
	7331	DG1 nom. power	60	kW	N/A	<ul> <li>Image: A set of the set of the</li></ul>	customer		N/A
	7333	DG1 P input	5		N/A	<ul> <li>Image: A set of the set of the</li></ul>	customer		N/A
	7335	DG2 Q input	6		N/A	<ul> <li>Image: A set of the set of the</li></ul>	customer		N/A
	7512	Ext. Comm.Speed	1		N/A		customer		N/A
	7520	Ext comm. error	N/A		10		customer		Warning
	7561	PV protocol	10		N/A		customer		N/A
	7562	Tx write type	1		N/A		customer		N/A
	7570	PV COMM error	N/A		3	<ul> <li>Image: A set of the set of the</li></ul>	customer		Warning
	7580	PV Warning	N/A		0	<ul> <li>Image: A set of the set of the</li></ul>	customer		Warning
	7590	PV Shutdown	N/A		0	<ul> <li>Image: A set of the set of the</li></ul>	customer		Shutdown
	9030	Scaling	0		N/A		master		N/A
	10980	Multi inp. conf. 102	0		N/A		customer		N/A
	10990	Multi inp. conf. 105	0		N/A		customer		N/A
	11000	Multi inp. conf. 108	0		N/A		customer		N/A